



Digital control panel

Abridged General View:

- Run/Stop: Press this key to run/stop the system.
- Fan: Press this key to enter the fan speed interface, press up and down key to adjust the speed. Keeping the key depressed continuously (more than three seconds) will enter the nature function.
- Pump: Press this key to RUN/STOP the pump (keeping the normal water level is necessary).
- TEM: Press this key to set the temperature, the DS1 display the current testing temperature, DS2 display the setting temperature, press down and up key to adjust the setting temperature.
- TIME: Adjust the time, press the down and up key to set the time, the Factory default is 60 minutes.
- UP: When adjusting the numerical value, press this key to increase the value, which adds numerical value for 1, Keeping the key pressed continuously will add the value for 10.
- DOWN: When adjusting the numerical value, press this key to reduce the value, which reduces the numerical value for 1, Keeping the key pressed continuously to reduce the value for 10.